

/ ULTRA96 Boards

11 June 2019

© 2019 Avnet. All rights reserved. All trademarks and registered trademarks are the property of their respective owners. All specifications are subject to change without notice.

NOTICE OF DISCLAIMER: Avnet is providing this design, code, or information "as is." By providing the design, code, or information as one possible implementation of this feature, application, or standard, Avnet makes no representation that this implementation is free from any claims of infringement. You are responsible for obtaining any rights you may require for your implementation. Avnet expressly disclaims any warranty whatsoever with respect to the adequacy of the implementation, including but not limited to any warranties or representations that this implementation is free from claims of infringement and any implied warranties of merchantability or fitness for a particular purpose.

Overview

The Ultra96-V2 ships with a blank microSD Card. For initial setup or if the microSD card has been erased or reprogrammed, then use this tutorial to restore the microSD card to the latest factory image.

Experiment Setup

Software

The software required for this tutorial is:

- Etcher -- <https://etcher.io/>
- Decompression utility, such as 7-zip

Hardware

The hardware setup used to test this reference design includes:

- Host machine compatible with Etcher
- 16 GB microSD card
- microSD adapter (to full-size SD or USB) that is compatible with your host machine
- Ultra96-V2
- 96Boards Power Adapter, such as Avnet AES-ACC-U96-4APWR

Instructions

The following procedure will write the Ultra96-V2 16GB microSD card with the latest factory image.

WARNING – This procedure will erase everything on the microSD card, so backup anything important prior to running performing this operation.

1. Download the image archive from <http://avnet.me/ultra96-v2-oob>
2. Decompress the archive to extract the .img file. You should have a file named ultra96v2_oob_2018_3_yymmdd.img where *yyymmdd* is the datecode of the image. The extracted image should be around 16,022,241,280 bytes large.
3. Download Etcher for your host at <https://etcher.io/> and install it.
4. Launch Etcher




Figure 1 – Etcher Launched

- Click **Select Image**. Browse to the `ultra96v2_oob_2018_3_yymmdd.img` previously extracted and click **Open**.




Figure 2 – Etcher with Ultra96-V2 Image Loaded

- Plug in the microSD card + adapter into your host and note the drive letter. Etcher may find your drive automatically. If not, click **Select Drive** and browse to the drive letter for your microSD card.




Figure 3 – Drive Selected in Etcher

WARNING – This procedure will erase everything on the microSD card, so backup anything important prior to running performing this operation.

7. Click **Flash!** to flash the microSD card.




Figure 4 – Flashing in Progress

When complete, Etcher will display “Flash Complete!”




Figure 5 – Flashing Complete

Conclusion

Once the microSD card is written, refer to the **Ultra96-V2 Getting Started Guide** for additional exercises. See www.avnet.me/ultra96-v2 → **Documentation**

Revision History

Date	Version	Revision
11 Jun 2019	01	Initial version