

Quickstart Guide miro Edge Sphere



1. Unboxing

- Edge Sphere Gateway
- LoRa® and LTE antenna
- USB power supply and cable

2. Installation

- Install the device far from metal objects
- Attach both labeled antennas (LTE and 868 MHz)
- Use supplied USB power adapter

3. Usage

Scan QR code or go to:

https://docs.miromico.ch/datasheets/gateways.html#_miro_edge_sphere



Gateway EUI is printed on the backside of the Gateway